

Заправка картриджей Kyocera

Артикул	Принтер, МФУ	Розница
TK-110	FS 720 / 820 / 920 / 1016MFP / 1116MFP	1500
TK-1110	FS-1040 / 1020MFP / 1120MFP	900
TK-1130	FS-1030MFP / DP/1130MFP / ECOSYS M2030DN	1000
TK-1120	FS-1060DN / FS-1025MFP / FS-1125MFP	900
TK-1140	FS-1035MFP DP / FS-1135MFP	1300
TK-1150	P2235dn/P2235dw/M2135dn/M2635dn/M2635dw/M2735dw	1000
TK-1160	ECOSYS P2040dn, P2040dw	1300
TK-1170	ECOSYS M2040dn / M2540dn / M2640idw	1300
TK-1170L	ECOSYS M2040dn / M2540dn / M2640idw	1500
TK-1200	ECOSYS M2235dn / P2335dw / M2835dw	1100
TK-1200L	ECOSYS M2235dn / P2335dw / M2835dw	2500
TK-130	FS 1300D / 1300DN / 1350DN / 1028MFP / 1028MFP DP / 1128MFP	1200
TK-3100	Fs-2100D / Fs-2100DN / Fs-2100 / M3040dn / M3540dn	1500
TK-3110	FS 4100	1500
TK-3130	FS-4200DN / FS-4300DN / ECOSYS M3550idn / ECOSYS M3560idn	2000
TK-3160	Kyocera ECOSYS P3055dn / P3060dn / P3045dn / P3050dn	1500
TK-3170	Kyocera ECOSYS P3050DN/P3055DN/P3060DN	2000
TK-3190	KYOCERA ECOSYS P3055dn, ECOSYS P3060dn	2500
TK-4105	TASKalfa 1800 / 2200 / 1801 / 2201	2500
TK-410	KM 1620 / 1635 / 1650 / 2020 / 2035 / 2050	3000
TK-435	TASKalfa 180 / 181 / 220 / 221	3000
TK-475	FS-6025MFP / FS-6025MFP/B / FS-6030MFP / FS-6525MFP / FS-6530MFP	2500
TK-6115	Kyocera ECOSYS M4125idn/M4132idn	2500