

**Заправка картриджей Хероx**

Артикул	Принтер, МФУ	Розница
106R04348	Xerox B205, Xerox B210, Xerox B215	800
106R00442	DocuPrint P1210	1000
106R02181	Phaser 3010 / 3040 / WC 3045	700
106R02183	Phaser 3010 / 3040 / WC 3045	800
106R02773	Phaser 3020 / WorkCenter 3025	900
106R01378	Phaser 3100MFP	1200
106R01379	Phaser 3100MFP	1400
109R00639	Phaser 3110	800
109R00748	Phaser 3116	800
106R01159	Phaser 3117 / 3122 / 3124 / 3125	800
013R00625	Phaser 3119	800
109R00725	Phaser 3120 / 3121 / 3130	800
108R00908	Phaser 3140 / 3155 / 3160	800
108R00909	Phaser 3140 / 3155 / 3160	900
113R00735	Phaser 3200MFP	700
113R00730	Phaser 3200MFP	800
106R01487	Phaser 3220/3210	900
106R01373	Phaser 3250	900
106R01374	Phaser 3250	1000
106R02778	Phaser 3052 / 3260 / WorkCentre 3215 / 3225	900
106R02782	Phaser 3052 / 3260 / WorkCentre 3215 / 3225	1100
106R01411	Phaser 3300MF	900
106R01412	Phaser 3300MF	1000
106R00646	Phaser 3310	900
106R02310	WorkCentre 3315	900
106R02304	Phaser 3320	900
106R02306	Phaser 3320	1500
106R01033	Phaser 3420 / 3450 / 3400	900
106R01034	Phaser 3420 / 3450 / 3400	1500
106R01245	Phaser 3428	900
106R01414	Phaser 3435 / 3500	900
106R01415	Phaser 3435 / 3500	1000
106R01370	Phaser 3600	1000
106R01371	Phaser 3600	1400
108R00794	Phaser 3635	1500
108R00796	Phaser 3635	1000
106R02736	WorkCentre 3655	600
106R02738	WorkCentre 3655	1200
113R00657	Phaser 4500	1400
113R00712	Phaser 4505 / 4510	1100
106R01534	Phaser 4600 / 4620	2000
106R01536	Phaser 4600 / 4620	3000
006R01573	Xerox WorkCentre 5019 / 5021	1100
106R01413	Phaser 5222	1100
113R00737	Phaser 5335	1100
113R00495	Phaser 5400	2000

113R00668	Phaser 5500	2400
106R00586	WC 312 / 412 / M15 / M15i	700
106R01485	WC 3210 / 3220	700
106R01486	WC 3210 / 3220	800
106R02308	WC 3315 / 3325	800
106R02310	WC 3315 / 3325	1100
106R02312	WC 3315 / 3325	1500
106R03620	Phaser 3330 / WC 3335 MFP / WC 3345 MFP	1500
106R03621	Phaser 3330 / WC 3335 MFP / WC 3345 MFP	2000
106R03623	Phaser 3330 / WC 3335 MFP / WC 3345 MFP	2500
013R00621	WC PE220	500